

## Glossary of Terms

The following glossary is a list of terms commonly used in the trade in Alberta and elsewhere in Canada. Individuals preparing for examinations should be familiar with these terms and how they are used in the context of the trade.

ABS	ECU	ROM
Allen wrenches	Emery cloth	Scavenging
Anti-drive	Fairings	Selenium rectifier
Anti-drive forks	Foot pegs	Sensor rheostat
Banjo bolts	Fuel petcock	Siamese crankshaft
Bendix	Gaiters	Spigot-mount carburetor
CDI	Heim joints	Symmetrical
Circlips	Helical gear	Tickler system
Cleave blocks	Heli-coil	Triple tree
Dead-blow hammer	Inclinometer	Trochoid
Desmodronic	Keystone	Tungsten inert gas (TIG)
DOT	Metal inert gas (MIG)	Waste gate
Dremel	PROM	Workplace Hazardous
Dyke	Rake	Materials System (WHMIS)